SIMONA AG Teichweg 16 • D-55606 Kirn Postfach 1 33 • D-55602 Kirn

Telefon (0 67 52) 14-0 Telefax (0 67 52) 14-211



SIMONA® PP-C-UV and SIMOPOOL PP in Swimming Pool Applications

To whom it may concern,

We would like to provide you with the following information regarding SIMONA® PP-C-UV and SIMOPOOL PP used in swimming pool applications:

- Please check and document the pH level, the level of free chlorine in the water and the temperature on a daily basis. The water should not contain more than 0.80 ppm free chlorine and the pH level should be between 7.0 and 7.6. The temperature of the swimming pool water should not exceed 40°C.
- Please avoid direct contact between chemical products and SIMONA® PP-C-UV and SIMOPOOL PP. Chemical products such as chlorine tablets have to be dissolved slowly in a floating dispenser and you have to ensure that the dispenser does not remain in the same position. If products in the form of powder, granules or liquids are used, they must be dissolved or diluted before adding them to the swimming pool water. Please operate the circulation pump continuously during dosing to avoid increased concentrations in specific areas of the pool.
- Please check the mineral content of the swimming pool water. Metallic components such as dissolved iron, manganese or copper can cause discoloration on the surface of SIMONA® PP-C-UV and SIMOPOOL PP. Also remove deposits of lime, grease, sunscreen and other dirt from the waterline.
- To avoid damaging the surface of the products, please do not use abrasive materials or abrasives.
- We recommend using only products from the same production batch for producing a swimming pool in order to ensure consistent coloration.

According to extensive quality assurance measures we assume that SIMONA® PP-C-UV and SIMOPOOL PP in colors:

dusty grey 1645, arctic white 1641, white 9002, light grey 1932, blue 924, grey 2266

are particularly suitable for use in swimming pool applications under operating conditions and periodical cleaning as given above.

If you have any questions about the application and processing of our products, our experts will be happy to assist you:

Technical Service Center

Phone: +49 (0) 6752 14-587 Fax: +49 (0) 6752 14-302 tsc@simona.de

All information furnished in this document reflects our current scope of knowledge on the date of publication and is designed to provide details of our products and potential fields of application (errors and omissions excepted, including typographical mistakes). In order to ensure that the document is up to date, this printout is only valid for the calendar year corresponding to the date printed. As at 18. Oktober 2022.